

Change AP-RO5500 Filter:

1. Turn off water source to filter
2. Turn off valve on top of storage tank.
3. Open faucet to relieve pressure
4. Turn cartridges left 1/4 turn, pull down, discard
5. Push new cartridges into heads and turn right 1/4 turn until stop
6. Turn on water supply to unit
7. Wait 10 minutes - then turn on storage tank valve
8. Allow tank to empty until steady drip
9. Close faucet - allow 6 hours to refill - empty again.

